

EtherFast® 10/100 Integrated CardBus PC Card

Model No.: PCM200 v2


INSTALLING THE HARDWARE:

1. Locate your PC's card slot (usually located on the side). Slide the EtherFast 10/100 Integrated CardBus PC Card into the slot with the triangle facing up. Ensure that the card is inserted firmly in place.
2. Attach one end of a Category 5 network cable into the RJ-45 port on the PC Card. Plug the other end of the cable into a Fast Ethernet or 10BaseT hub.

You are now ready to install the network driver.


INSTALLING THE NETWORK DRIVER

1. Start your computer and boot up Windows 2000.
2. Windows will display the *Found New Hardware Wizard* box.




Click **Next**.

3. The *Install Hardware Device Drivers* dialog box will appear.



When *Ethernet Controller* is displayed, select “*Search for a suitable driver for your device (Recommended)*”. Click **Next**.

4. The *Locate Driver Files* dialog box will appear.




Quick Installation For Windows 2000

This sheet will guide you through the basic steps needed to install this Linksys product on your computer. If you have any problems during installation, visit our support page at www.Linksys.com.

Select the “*Floppy disk drives*” option, insert the *Linksys EtherFast 10/100 Integrated CardBus PC Card Driver Disk* into your floppy drive. Click **Next**.

5. The *Driver File Search Results* dialog box will appear. Click **Next**.



6. The *Completing the Found New Hardware Wizard* dialog box will appear.



The following adapter name will be shown:

*Linksys EtherFast 10/100 Integrated
CardBus PC Card II*

Click **Finish**.

7. Remove any Driver Disks from your floppy drives.

Installation is complete.

**If you want to share files or printers,
refer to the Windows 2000 documentation**



Note: Do not click *Cancel* or *Skip* at any time during the installation process. Doing so will prevent your driver from being properly installed on your PC.